

Revision No. 1	Page 1 of 3	<div>Technical Definition</div> <div>Chemical analysis on Rene 77</div>
<div>ptp.</div>		
Kit 8-5-2022 PTP Metallic		

You shall respect the HSE policy of your laboratory for each performed test.

Please read these instructions carefully BEFORE starting the tests.

- One blank (Ø 25 x 25) is supplied to each participant. Laboratory shall submit a report for each accredited element and accredited method provided.
In case of loss or deterioration of your PTP sample, please contact your sponsor for a replacement kit.
- For each method, the laboratory shall report **one value** according to its usual process. The laboratory shall also indicate how many analyses were performed to obtain this result.

- One technician shall perform all analyses.
- Each participant is required to report the following elements to the indicated precision regardless of their normal practice. **The elements below the quantified detection limit shall not be reported.**

Element	Symbol	Precision (%)	Indication
Carbon	C	X,XX	<0.10
Cobalt	Co	X,XX	<20.00
Chromium	Cr	X,XX	<20.00
Aluminium	Al	X,XX	<10.00
Molybdenum	Mo	X,XX	<5.00
Titanium	Ti	X,XX	<5.00
Iron	Fe	X,XX	<1.00
Boron	B	X,XXX	<1.000
Zirconium	Zr	X,XX	<0.10
Manganese	Mn	X,XX	<0.10
Silicium	Si	X,XX	<0.10
Copper	Cu	X,XX	<0.0001
Sulfur	S	X,XXX	<0.010
Bismuth	Bi	X,XXXXX	<0.00001
Silver	Ag	X,XXXX	<0.0001
Lead	Pb	X,XXXX	<0.0001
Oxygen	O	X,XXXX	<0.0100
Nitrogen	N	X,XXXX	<0.0100
Platinum	Pt	X,XXXX	<0.0010
Rhenium	Re	X,XXXX	<0.1000
Palladium	Pd	X,XXXX	<0.0010

As AMS standard is not available for this material, you can find an indication about maximum concentration for each element.

All evaluated characteristics will be analysed according to the algorithm A (ISO 13528 – 2015) and evaluated using z-score. **The results will be taken into account for the analysis only if the element and the method are within the accreditation scope of the laboratory.**

- Each element shall be reported in Percent Concentration, to the precision (the number of significant digits) indicated.

Revision No. 1	Page 2 of 3	<div>Technical Definition</div> <div>Chemical analysis on Rene 77</div>
<div>ptp.</div>		
<div>Kit 8-5-2022 PTP Metallic</div>		

The provided results shall be within the analytical range of the laboratory. If a laboratory is not able to provide results with the required precision, **the values shall not be reported.**

Non-quantified elements, such as “less than”, “not detected,” etc., shall not be reported.

Elements shall not be reported in PPM or any other unit of measurement than Percent Concentration.

5. Testing shall start **as soon as test specimens are received**. Please contact the following e-mail address for any technical or administrative query.

Shipment date from:	January 2022
Submission date :	May 1st, 2022
Technical and administrative support :	info@ptpscheme.com

6. Instructions for submission of results are detailed on the website:

<https://ptpscheme.com>

7. To ensure the confidential treatment of your results in the final report, you will be allocated a unique identity number when you register for the program.
8. Collusion and falsification of your PTP results are totally forbidden. In case of identification or suspicion of collusion or falsification, the laboratory will be excluded from the program and the sponsors will be immediately informed. The sponsors could ask you proofs of your records and analyses, so be sure to conserve data, curves and specimens.

Revision No. 1	Page 3 of 3	<div>Technical Definition</div> <div>Chemical analysis on Rene 77</div>
<div>ptp.</div>		
<div>Kit 8-5-2022 PTP Metallic</div>		

APPENDIX : Instructions for IRR participation

The Internal Round Robin participation (IRR) is **optional** and **independent** from your PTP participation. The extra samples shall be tested according to the following table:

	Operator 1	Operator 2	Operator 3	Operator 4	Operator X
Test machine 1	PTP kit (1 sample)	1 sample	1 sample	1 sample	1 sample
Test machine 2	1 sample				
Test machine 3	1 sample				
Test machine Y	1 sample				

Operator 1 (OP1) is to be the most experienced operator currently conducting tests on a regular basis and shall perform tests on all machines (TM1, TM2, TM3...)

Test Machine 1 (TM 1) is to be the most utilised machine for this test in your laboratory and shall be tested by all operators (OP1, OP2, OP3...)

Example: A laboratory has 2 operators and 3 test machines. They receive a PTP kit and 3 extra specimens.

Operator 1 shall test the PTP kit on TM1, 1 specimen on TM2 and 1 specimen on TM3.

Operator 2 shall test 1 specimen on TM1.

The IRR results have to be submitted on a separate results form available on the PTP website.

The identification of operators and test machines you provide will appear on the IRR final report. These identifications will not be seen by other laboratories.

The IRR results will be classified against the acceptance classes of the kit 8-5-2022.

Reminder: Laboratories are not permitted to switch specimens between the PTP kit and IRR samples.

REVISION HISTORY

Issue Date	Issue N°	Changes
25/01/2021	1	Document creation